



SL-LED Series

Light Source and Universal LED Controller



| Version No. | Description | Date | Author | Approved |
|-------------|-------------------------|------------|-----------|--------------|
| 1.0 | Manual Launch | March 2015 | S. Turner | |
| 1.1 | Manual Update | June 2016 | A. Dixon | |
| 2.1 | Manual Update | Oct 2016 | A. Dixon | M. Nicholson |
| 2.2 | Manual Update | May 2019 | M. Dutka | M. Nicholson |
| 2.3 | Minor notes | July 2019 | M. Dutka | M. Nicholson |
| 3.0 | New model - SL-LED 324S | June 2020 | M. Dutka | M. Nicholson |

Table of Contents

| | |
|--|---------|
| Introduction | Page 4 |
| Operating Principle | Page 4 |
| Technology | Page 4 |
| SL-LED-CTRL Series: Universal LED Controller | Page 5 |
| Technical Specifications | Page 6 |
| Technical Drawings | Page 7 |
| Product Components | Page 9 |
| Programming the Universal LED Driver: PC Configuration Tool | Page 10 |
| Info Tab | Page 14 |
| Operation Mode Tab | Page 15 |
| Flash Code | Page 16 |
| Intensity | Page 17 |
| Sensors | Page 18 |
| AIS Report | Page 22 |
| Optional GPS Synchronisation | Page 23 |
| Optional GSM Monitoring | Page 24 |
| Light Source & Pedestal Installation | Page 25 |
| Manual Information | Page 26 |
| External Antenna, GSM | Page 28 |
| External Antenna, GPS | Page 28 |
| External Light Sensor (PE Cell) | Page 29 |
| Maintenance | Page 30 |
| Trouble Shooting | Page 31 |
| Sealite LED Light Warranty | Page 31 |



Introduction

Congratulations! By choosing to purchase a Sealite lantern you have become the owner of one of the most advanced LED marine lanterns in the world.

Sealite Pty Ltd has been manufacturing lanterns for over 25 years, and particular care has been taken to ensure your lantern gives years of service.

As a commitment to producing the highest quality products for our customers, Sealite has been independently certified as complying with the requirements of ISO9001:2015 quality management system.

Sealite lanterns comply with requirements of the US Coast Guard in 33 CFR part 66 for Private Aids To Navigation.

By taking a few moments to browse through this booklet, you will become familiar with the versatility of your lantern, and be able to maximise its operating function.

Operating Principle

A microprocessor drives an array of ultra-bright LED's through a DC/DC converter, which enables the LED's to operate within the manufacturer's specifications.

On darkness, the microprocessor will initiate a program check and after approximately 1 minute begin flashing

to the set Flash Character.

The flasher unit has a low current requirement to optimise its use with external battery power supply systems.

Technology

Sealite is the world's fastest growing manufacturer of marine aids to navigation. We employ leading mechanical, optical, hardware & software engineers to create innovative products to service the needs of our customers worldwide, and offer the widest range of solar-powered LED lanterns in the marketplace.

Electronics

Sealite employs leading in-house electronic engineers in the design and development of software and related circuitry. All individual electronic components are sourced directly by Sealite procurement staff ensuring that only the highest quality components are used in our products.

LED Technology

All marine lanterns use the latest advancements in LED (Light Emitting Diode) technology as a light source. The major advantage of LED's over traditional light sources is well established in that they typically have an operational life in excess of 100,000 hours, resulting in substantial savings to maintenance and servicing costs.

Precision Construction

Commitment to investing in the design and construction of injection-moulded parts including optic lenses, light bases and a range of other components ensures that all Sealite products are of a consistent & superior quality.

Optical Performance

Sealite manufactures a range of marine LED lenses moulded from multi-cavity dies. The company has superior in-house lens manufacturing capabilities to support outstanding optical performance.

Award-winning, Patented Technology

Several United States and Australian patent registrations are held on Sealite's range of innovative designs, with other regional patents pending in Canada, United Kingdom and Europe.

SL-LED-CTRL Series

Universal LED Controller

Sealite's LED Universal Controller is used in conjunction with the LED Light Source. Developed using the most advanced engineering and software technology, the Universal Controller is designed to control power to the Light Source in a small form factor.

It can be configured with AIS, GPS and GSM capabilities, providing cutting-edge monitoring of a light source's LED status, power supply, temperature and turntable rotation speed. Advanced programming can be incorporated for intensity settings, complex flash configurations, and alarm conditions.



Technical Specifications

| | SL-LED LIGHT SOURCE | |
|---|---------------------|---------------------|
| Light Source Characteristics | SL-LED 324S | SL-LED 324 |
| Maximum Power Rating (W) | Variable up to 200W | Variable up to 200W |
| Number of LEDs in Array | 36 | 36 |
| LED Height (cm) | 1.2 | 1.6 |
| Average LED Width | 1.89 | 2.57 |
| LED Area (cm ²) | 2.27 | 4.11 |
| Average Horizontal Intensity (cd) | 2642 | 2499 |
| Nominal Average Luminance (cd/cm ²) | 1165 | 608 |





Please note: The quoted figures above are for peak outputs when operating at 100% intensity. The maximum recommended power duty cycle including flash character is 50% for low to moderate temperature environments (up to 40°C / 104°F). The system includes thermal monitoring of the light source and controller.



| | SL-LED CONTROLLER |
|---------------------------------|---|
| Controller Characteristics | SL-LED-CTRL |
| Available Flash Characteristics | Up to 310 including 256 IALA recommended |
| Intensity Adjustments | User adjustable |
| Electrical Characteristics | |
| Circuit Protection | Polarity protected |
| Nominal Voltage | VDC Model: 18–32VDC VAC Model: 110–240VAC |
| Temperature Range | -40 to 60°C |
| External 3rd Party Monitoring | Via RS232/422/485 |
| AIS Connection | Via RS232/422/485 (if built-in module not selected) |
| Alarm Contacts | 1 x Volt free 250VAC @ 5A or 30VDC @ 5A |
| External Inputs | 2 x general purpose digital inputs 3–24VDC |
| External Outputs | 2 x general purpose digital outputs will switch up to 24VDC @ 1A |
| Physical Characteristics | |
| Body Material | Baked enamel coated aluminium |
| Mounting | 4 x 6mm screws (preferred mounting landscape) |
| Height (mm/inches) | 111 / 4½ |
| Width (mm/inches) | 400 / 15¾ |
| Depth (mm/inches) | 230 / 9 |
| Weight (kg/lbs) | 5 / 11 |
| Product Life Expectancy | Up to 12 years |
| Environmental Standards | |
| Low Temperature | MIL-STD-810G Method 502.5 |
| High Temperature | MIL-STD-810G Method 501.5 |
| Humidity | 0 – 100%, condensing |
| Certifications | |
| CE & Electrical | EN61000-6-2:2005, IEC61000-4-2:2008, IEC61000-4-3:2010, IEC61000-6-1:2016 |
| Quality Assurance | ISO9001:2015 |
| Waterproof | IP67 |
| Intellectual Property | |
| Trademarks | SEALITE® is a registered trademark of Sealite Pty Ltd |
| Warranty * | 3 years |
| Options Available | <ul style="list-style-type: none"> • AIS Type 1 or Type 3 • GSM Monitoring & Control System • Solar Power • Float charged battery standby systems • GPS antenna for synchronisation of flashing lights |



• Specifications subject to change or variation without notice * Subject to standard terms and conditions
† Intensity setting may vary in accordance with manufacturing tolerances (+/-10%)

Universal LED Controller





Product Components


The following components come standard with each lantern:-

- SL-LED-CTRL (Universal LED Controller)
- USB Drive comprising of a PC based Lantern Configuration Tool
- Programming cable
- Installation & service manual

These components are securely packaged within foam in a carton, and shipped to you.

PLEASE NOTE: The programming cable provided is suitable for use with PC's. If you require connection to your notebook/laptop, a Serial Port to USB cable may need to be purchased.

Please check that ALL of these components are included with your order, and contact your Sealite representative as soon as possible if anything is missing.





Programming the Universal LED Driver

PC Configuration Tool

Upon request, the Universal LED Driver can be pre-programmed to the customer's specific requirements for convenience (eg. flash, intensity setting etc).

The SL-LED-CTRL Series are extremely intelligent LED controller lanterns with a number of features which can be programmed directly via a user-friendly computer program (as supplied on USB drive with every lantern).

To change/update the settings of your lantern, please read the following instructions.

1. Run the Programming Software

The programming software may be run directly from the USB drive provided, or you may copy the software to your computer hard-drive for future use.

Running the Programming Software from the USB Drive

- Connect the USB drive to your computer.
- Navigate to the USB drive folder & double-click the file called "LanternConfig.exe". A new window will appear displaying the PC Configuration Tool.

Saving the Programming Software to Computer Hard-Drive

- Connect the USB drive to your computer.
- Navigate to the USB drive folder.
- Copy the file called "LanternConfig.exe" and the ".dll" files
- Navigate to the hard-drive location where you would like to save this program, and then right mouse-click and select "paste". A copy of the programming software will now be saved to your computer hard-drive (to add the programmer to your computer desktop for ease of future access, right-mouse-click and select "Send to desktop").
- Double-click the file called "LanternConfig.exe". A new window will appear displaying the PC Configuration Tool

PLEASE NOTE: Other documents have been saved on the USB drive for your information & convenience including the latest product specifications sheet and an electronic version of the installation and service manual. You may wish to view these documents to read more about the innovative features and benefits of the SL-LED-CTRL Series.

IMPORTANT: The Sealite PC Configuration Tool is designed for Windows Platforms only.

Lantern Configuration Tool Version 2.07 AUS Eastern Standard Time: Wednesday, 01/Jun/2016 08:55:39AM

COM Setup Help



Info Operation Mode Flash Code Intensity Sensors Report

Version

Master Software Version 0.42 SL324, CUB1019 Master
Master Hardware Version PCB1409 Rev3A
Slave Software Version 0.42 SL324, CUB1019 Slave
Slave Hardware Version PCB1409 Rev3A

Lantern Summary

Colour White
Operation Mode Dusk till Dawn
Adv Operation Mode All LEDs
Flash Code (Dec) 017
Sync Offset (Sec) 0.00
Intensity 90.63%

Name

Set Name

LED Colour



Event Log

Set Date

Clear

Save

Image 1. Sealite PC Configuration Tool



2. Connect the SL-LED-CTRL Series Lantern to a Power Source & the Computer

Now that the programming software has been run, you will need to connect the lantern to your computer & power supply so that it can receive programming commands.

Once connection is made, the software automatically determines the colour and pre-programmed settings of the Universal LED Controller after the unit is powered up.

Connecting the SL-LED-CTRL to a Power Source

Option 1: Battery or 24VDC Power Supply

- Connect the High Output LED Light Source to the Universal LED Controller.
- Connect the blue negative wire of the lantern to the battery negative terminal
- Connect the brown positive wire of the lantern to the battery positive terminal

Option 2: 110/240V Power Supply

- Connect the High Output LED Light Source to the Universal LED Controller.
- Connect both mains cables to the IEC317 socket on the side of the enclosure.

Connecting the Lantern to the Computer

- Plug the Bulgin connector end of the programming cable into the lantern PC Programming Port, and the serial port end of the cable into your computer serial/communication port (RS232-E)

PLEASE NOTE: The programming cable provided is suitable for use with desktop PC's. If you require connection to your notebook/laptop, a Serial Port to USB cable may need to be purchased.

3. Establish the Programmer-to-Lantern Computer Connection (COM Port)

Now that the lantern is connected to the computer and the Sealite PC Configuration software has been run, the user must create the programmer-to-lantern connection.

The COM Port is the hardware port which the computer accesses when communicating with the lantern.

- Click the "COM Setup" at the top left of the PC Configuration Tool to open the "Serial Port" dialogue box
- In the "Serial Port" dialogue box select the appropriate COM Port from the drop down field for "Port Name"
- Check the "Open Port" check box to open the port
- Click the "OK" button to initiate the connection

The Sealite PC Configuration Tool will then attempt to connect/interrogate the lantern.




Image 2. Serial Port dialogue box

Correct Connection Established

If the connection is established data about the lantern configuration will appear on the “Info” tab under the headings “Version” & “Lantern Summary” (eg. Lantern Colour, Flash Code, Intensity etc).

Lantern Configuration Tool Version 2.07 AUS Eastern Standard Time: Wednesday, 01/Jun/2016 08:55:39AM

COM Setup Help

Info Operation Mode Flash Code Intensity Sensors Report

Version

Master Software Version 0.42 SL324, CUB1019 Master

Master Hardware Version PCB1409 Rev3A

Slave Software Version 0.42 SL324, CUB1019 Slave

Slave Hardware Version PCB1409 Rev3A

Lantern Summary

Colour White

Operation Mode Dusk till Dawn

Adv Operation Mode All LEDs

Flash Code (Dec) 017


Sync Offset (Sec) 0.00

Intensity 90.63%

Name

Set Name

LED Colour



Event Log Set Date

Clear Save

Connection NOT Established

If the connection is not available, the Sealite PC Configuration Tool will not display any lantern specific information under the headings “Version” & “Lantern Summary”. If this error occurs, please check the following:

- Reconnect the lantern to the computer
- Check that the lantern power supply has sufficient charge (eg. battery is charged), and then reconnect it to the lantern
- Re-run the Sealite PC Configuration Tool and follow the information in step 3. The connection should now become established.

The Sealite lantern is now ready to be programmed to your specific requirements.



Info Tab

Lantern Configuration Tool Version 2.07 AUS Eastern Standard Time: Wednesday, 01/Jun/2016 08:55:39AM

COM Setup Help

Info Operation Mode Flash Code Intensity Sensors Report

Version

Master Software Version 0.42 SL324, CUB1019 Master

Master Hardware Version PCB1409 Rev3A

Slave Software Version 0.42 SL324, CUB1019 Slave

Slave Hardware Version PCB1409 Rev3A

Lantern Summary

Colour White

Operation Mode Dusk till Dawn

Adv Operation Mode All LEDs

Flash Code (Dec) 017

Sync Offset (Sec) 0.00

Intensity 90.63%

Name

Set Name

LED Colour



Event Log

Set Date

Clear Save

Provides a summary of the lantern configuration settings, hardware and software versions, and event log.

Version

Is an information panel that identifies the Lantern's internal electronic hardware and firmware versions.

Lantern Summary

Is an information panel that displays a summary of the key lantern settings: colour, operation mode, Peak Intensity setting, Advance Operational Mode, Flash Code, Flash Sync offset and Intensity setting. Refer to the Information, Operation Mode Flash Code, and Intensity Tabs for a description of these parameters.

Name

A user defined name, comprising alphanumeric characters (and -, \$, #, @) can be typed into dialogue box and by pressing and stored within the lantern's non-volatile memory by pressing the 'Write Name' button.

LED Colour


A generic picture of the lantern model and colour that the software tool is communicating with is displayed in this panel.

Event Log

Displays the alarm events recorded by the lantern firmware. Possible alarms (flat battery, low battery, LED failure, high temperature). All alarm events are recorded irrespective of whether the lantern has been configured to respond to an alarm.

- To set the date, click 'Set Date', choose date and time, press 'Send'
- To clear the event log, click 'Clear' and select 'Yes'

Operation Mode Tab



Defines the lanterns mode of operation of which there are four possibilities:

Operational Mode

- **Standby**
The lantern is configured in a minimum current state in which the LEDs are always off and the internal GPS (if installed) is disabled.
- **Always On**
The daylight sensor is disabled and the lantern operates according to the set flash character and intensity levels.
- **Dusk till Dawn**
The daylight sensor is monitored and the lantern will only operate at night time.

Adv Op Mode

This is an advanced user mode and typically only used if the lantern is to be used as a special navigational aid such as emergency wreck mark. Not applicable.

All

Default on setting. All LEDs are operated in unison and configured by the Operation Mode, Flash Code and Intensity Tabs.

Reset

By clicking Reset, the factory set default parameters are restored.

Pulse Shape

This is an advanced user mode. It allows the Rising and Falling edge of the flash to be adjusted.



Flash Code

Lantern Configuration Tool Version 2.07 AUS Eastern Standard Time: Wednesday, 01/Jun/2016 09:21:19AM

COM Setup Help

Info Operation Mode Flash Code Intensity Sensors Report

Mariner Characteristic Selection

Mariner Code:

Flash Code Name:

Flash Code (Dec): Timing:

Current Code: F

Sealite Code Selection

☒ IR Flash Code ☐ Switch Flash Code

Current Code (Dec): 000

Sync Offset (Sec) (Max=5.1Sec)

(Note: GPS antenna must be connected to utilise this feature.)

Current Sync Offset: 0.00

Manual Entry Custom Flash Code (999) Timings

| On (Sec) | Off (Sec) | On (Sec) | Off (Sec) |
|-----------------------------------|-----------------------------------|----------|-----------|
| <input type="text" value="0.30"/> | <input type="text" value="0.90"/> | | |
| <input type="text"/> | <input type="text"/> | | |
| <input type="text"/> | <input type="text"/> | | |
| <input type="text"/> | <input type="text"/> | | |
| <input type="text"/> | <input type="text"/> | | |
| <input type="text"/> | <input type="text"/> | | |
| <input type="text"/> | <input type="text"/> | | |
| <input type="text"/> | <input type="text"/> | | |
| <input type="text"/> | <input type="text"/> | | |

(Note: Choose FFF or 999 to enable a special flash code.)

Marine Characteristic Selection

The flash character is defined by first selecting the Mariner code, then the Flash code name and finally timing.

Sealite Code Selection

This is an alternative method to select the lantern flash code by using Sealite rotary switch flash character setting.

Sync Offset

This panel is used to set a fixed delay to the commencement of the flash character. The built-in GPS receiver and advanced software of the Sealite synchronised lanterns allow for the adoption of SeaFlare™ channel marking – a unique system that cascades the flash synchronisation of channel lanterns in a uni- or bi-directional flash pattern. By default this figure is set to zero.

Manual Entry Custom Flash Character

In this panel a, custom flash characteristics can be defined with up to 10 individual on/off times. When entering a custom code with a duty cycle of 50% or more the controller must be power cycled to take effect.

Intensity

Lantern Configuration Tool Version 2.07 AUS Eastern Standard Time: Wednesday, 01/Jun/2016 09:22:22AM

COM Setup Help

Info Operation Mode Flash Code **Intensity** Sensors Report

Lantern Intensity

LED Current (A) 2.25

Percentage (%) 75 **Set**

Current Intensity White 43.75%

(Note: Set all LEDs with the same intensity.)

Lantern Intensity

| LED | Percentage (%) |
|-------|-----------------------------|
| LED1 | 43.75% <input type="text"/> |
| LED2 | 43.75% <input type="text"/> |
| LED3 | 43.75% <input type="text"/> |
| LED4 | 43.75% <input type="text"/> |
| LED5 | 43.75% <input type="text"/> |
| LED6 | 43.75% <input type="text"/> |
| LED7 | 43.75% <input type="text"/> |
| LED8 | 43.75% <input type="text"/> |
| LED9 | 43.75% <input type="text"/> |
| LED10 | 43.75% <input type="text"/> |
| LED11 | 43.75% <input type="text"/> |
| LED12 | 43.75% <input type="text"/> |

Set

(Note: To disable a LED set the intensity to 0%)

Lantern intensity

The lantern intensity level for each LED can be set by either by defining the operating LED current of the or by entering a desired peak candela or a percentage of maximum peak intensity level.

If an intensity level is selected that is beyond the specification of the lantern, the entered figure will be displayed in red coloured text, and the lantern will be configured to its maximum.



Sensors

Lantern Configuration Tool Version 2.31 AUS Eastern Daylight Time: Monday, 21/Nov/2016 10:30:30AM

COM Setup Help

Info Operation Mode Flash Code Intensity **Sensors** Other Report

Battery Sensor

(Note: Advanced users ONLY)

| Flat (V) | Low (V) | OK (V) | Master (V) |
|----------|---------|--------|------------|
| 22.0 | 23.0 | 25.0 | 24.4 |

Default (V) 22.0 23.0 25.0

When battery voltage is low:

- ☒ Reduce intensity to 75% of current value.
- ☒ Turn off GPS.
- ☒ Trigger alarm relay.

Set

LED Sensor

When an LED has failed:

- ☒ Turn off all LEDs.
- ☒ Trigger alarm relay.

Set

Temperature Sensor

☒ °C/°F (Note: Advanced users ONLY)

| High (°C) | OK (°C) | External | Master (°C) | Slave (°C) |
|-----------|---------|----------|--------------|------------|
| 85 | 80 | | 0 | 68 |
| | | | Default (°C) | 85 80 |

| High (°C) | OK (°C) | Internal | Master (°C) | Slave (°C) |
|-----------|---------|----------|--------------|------------|
| 80 | 75 | | 23 | 22 |
| | | | Default (°C) | 80 75 |

When temperature is high:

- ☒ Reduce intensity to 75% of current value.
- ☒ Trigger alarm relay.

Set

Light Sensor

(Note: Use current value to set up external light sensor.)

| | Day (Dawn) | Night (Dusk) | Current | Default |
|---------------------|------------|--------------|---------|-----------|
| External (Raw Data) | 2800 | 2400 | 2660 | 150 100 |

☒

When light sensor fails:

- ☒ Turn off all LEDs.
- ☒ Turn on all LEDs.
- ☒ Trigger alarm relay.

Set

Battery sensors

The SL-LED-CTRL driver continuously monitors its input voltage using three definable thresholds.

- For voltages greater than “OK” level, the lantern reports via IR Remote control requests or the GSM that the input voltage is satisfactory.
- For voltages below “low” the lantern can be configured to operate the internal alarm relay and / or reduce the intensity level by 25% as a measure to extend the operation of the lantern until it reaches the “Fail” voltage.
- At “Fail” the lantern shuts down entirely, and turns of the GPS and the mains LEDs. The lantern will only commence operation once the input voltage has exceeds the “OK” voltage level.

The three thresholds:

- Flat
- Low
- OK are user definable.

Lantern Configuration Tool Version 2.31 AUS Eastern Daylight Time: Monday, 21/Nov/2016 10:30:30AM

COM Setup Help

Info Operation Mode Flash Code Intensity Sensors Other Report

Battery Sensor (Note: Advanced users ONLY)

| Flat (V) | Low (V) | OK (V) | Master (V) |
|----------------------|----------------------|----------------------|----------------------------|
| 22.0 | 23.0 | 25.0 | 24.4 |
| <input type="text"/> | <input type="text"/> | <input type="text"/> | Default (V) 22.0 23.0 25.0 |

When battery voltage is low:

- ☒ Reduce intensity to 75% of current value.
- ☒ Turn off GPS.
- ☒ Trigger alarm relay.

Set

LED Sensor

When an LED has failed:

- ☒ Turn off all LEDs.
- ☒ Trigger alarm relay.

Set

Temperature Sensor ☒ °C/°F (Note: Advanced users ONLY)

| High (°C) | OK (°C) | External | Master (°C) | Slave (°C) |
|----------------------|----------------------|----------|--------------------|------------|
| 85 | 80 | | 0 | 68 |
| <input type="text"/> | <input type="text"/> | | Default (°C) 85 80 | |

| High (°C) | OK (°C) | Internal | Master (°C) | Slave (°C) |
|----------------------|----------------------|----------|--------------------|------------|
| 80 | 75 | | 23 | 22 |
| <input type="text"/> | <input type="text"/> | | Default (°C) 80 75 | |

When temperature is high:

- ☒ Reduce intensity to 75% of current value.
- ☒ Trigger alarm relay.

Set

Light Sensor (Note: Use current value to set up external light sensor)

| Day (Dawn) | Night (Dusk) | Current | Default |
|----------------------|----------------------|---------|---------|
| 2800 | 2400 | 2660 | 150 100 |
| <input type="text"/> | <input type="text"/> | | |

External (Raw Data)

When light sensor fails:

- ☒ Turn off all LEDs.
- ☐ Turn on all LEDs.
- ☒ Trigger alarm relay.

Set

Temperature

The SL-LED-CTRL utilises two temperature sensors. One that monitors the temperature of the master board, and the slave board and another that monitors the temperature of the LED Light Source via an in-built thermistor.

The temperature can be set to either Degrees Celsius or Degrees Fahrenheit. Click the box to switch between the different temperatures.

Each sensor has two configurable temperature thresholds: "High" and "OK". There are also two configurable options for when the "High" temperature threshold is exceeded:

- "Reduce intensity to 75% of current value".
- "Trigger alarm relay".

When the "High" temperature threshold is exceeded for either board, any of the selected options will be acted upon. The enabled options will remain active until the board temperatures both reduce to below the "OK" threshold.

Light Sensor

The SL-LED-CTRL lantern has its own external light sensor and whose day/twilight/night thresholds are defined in LUX. These levels can be customised by entering in separate values as a measure of LUX.

NOTE:

Twilight: this refers to the time between Day and Night.

Due to the placement of some Aids to Navigation in regards to the position of the sun, some ports may find it advantageous to adjust these settings accordingly.



LED Sensor

Built into the SL-LED-CTRL driver, is a closed loop monitoring system for each LED. In the event of a single LED failure, the lantern can be configured to trigger the internal alarm relay which in turn, can be connected externally to trigger other devices, such as redundant light source.

The screenshot shows the 'COM Setup' window with the 'Sensors' tab selected. It contains four configuration panels:

- Battery Sensor** (Note: Advanced users ONLY):
 - Fields: Flat (V): 22.0, Low (V): 23.0, OK (V): 25.0, Master (V): 24.5, Default (V): 22.0, 23.0, 25.0
 - When battery voltage is low:
 - ☒ Reduce intensity to 75% of current value.
 - ☒ Turn off GPS.
 - ☒ Trigger alarm relay.
 - Set button
- LED Sensor**:
 - When an LED has failed:
 - ☒ Turn off all LEDs.
 - ☒ Trigger alarm relay.
 - Set button
- Temperature Sensor** (Note: Advanced users ONLY):
 - High (°C): 85, OK (°C): 80, External Master (°C): 0, Slave (°C): 68, Default (°C): 85, 80
 - High (°C): 80, OK (°C): 75, Internal Master (°C): 24, Slave (°C): 23, Default (°C): 80, 75
 - When temperature is high:
 - ☒ Reduce intensity to 75% of current value.
 - ☒ Trigger alarm relay.
 - Set button
- Rotation Sensor** (Note: The general purpose digital connector must be connected.):
 - Target Speed (0 is Disabled): RPM (0.20 - 10): 0, Sec (6 - 300): 0, Current Speed: 0 (RPM), 0 (Sec)
 - Tolerance 10 (N): 10, Default: 0 (RPM), 0 (Sec)
 - When rotation stops:
 - ☒ Turn off all LEDs.
 - ☒ Trigger alarm relay.
 - When speed is outside of tolerance:
 - ☒ Turn off all LEDs.
 - ☒ Trigger alarm relay.
 - Set button

Rotation Sensor

Existing sensors may be interfaced with the controller depending on electrical parameters. Some sensors may not be shared with other equipment. Please consult with Sealite for details.

Sealite recommends Omron type E2B-M12KS04-WP-B1 and it may be wired directly to the enclosure or via the Pedestal connecting cable assembly.

The software allows users to define the expected rotation speed and a tolerance on this value for the purpose of setting an alarm condition in the event the rotating speed varies outside of the tolerance. The current speed and as detected by the SL-LED-CTRL driver is displayed.

Lantern Configuration Tool Version 2.31 AUS Eastern Daylight Time: Monday, 21/Nov/2016 10:30:10AM

COM Setup Help

Info Operation Mode Flash Code Intensity Sensors Other Report

Battery Sensor (Note: Advanced users ONLY)

| Flat (V) | Low (V) | OK (V) | Master (V) |
|----------|---------|--------|------------|
| 22.0 | 23.0 | 25.0 | 24.4 |

Default (V) 22.0 23.0 25.0

When battery voltage is low:

☒ ☐ Reduce intensity to 75% of current value.

☒ ☐ Turn off GPS.

☒ ☐ Trigger alarm relay.

Set

LED Sensor

When an LED has failed:

☒ ☐ Turn off all LEDs.

☒ ☐ Trigger alarm relay.

Set

Temperature Sensor ☒ °C/°F (Note: Advanced users ONLY)

| High (°C) | OK (°C) | External | Master (°C) | Slave (°C) |
|-----------|---------|----------|-------------|------------|
| 85 | 80 | | 0 | 68 |

Default (°C) 85 80

| High (°C) | OK (°C) | Internal | Master (°C) | Slave (°C) |
|-----------|---------|----------|-------------|------------|
| 80 | 75 | | 23 | 22 |

Default (°C) 80 75

When temperature is high:

☒ ☐ Reduce intensity to 75% of current value.

☒ ☐ Trigger alarm relay.

Set

Light Sensor (Note: Use current value to set up external light sensor)

| Day (Dawn) | Night (Dusk) | Current | Default |
|------------|--------------|---------|---------|
| 2800 | 2400 | 2660 | 150 100 |

External (Raw Data) ☒ ☐

When light sensor fails:

☒ ☐ Turn off all LEDs. ☒ ☐ Turn on all LEDs.

☒ ☐ Trigger alarm relay.

Set

Relay Mode

The relay can be set to different modes:

Normal:

The relay is in normal mode. It is powered and when an event occurs, power is cut.

Inverted:

The relay is inverted. When an event occurs, the relay is powered.

Off:

The relay is turned off.

GPS Mode

To reduce the power consumption in your Lantern over a 24 hour period, it is now possible to change the number of times the GPS module activates. The default setting is Normal:

- Off:**

The GPS is turned off.

- Normal:**

The GPS is turned off for 15 minutes (Night) and 30 minutes (Day).

- Fast:**

The GPS is only turned off for 5 minutes (Night) and 10 minutes (Day).

- On:**

The GPS is always on.



AIS Report



Lantern Status

This panel displays the lantern's AIS message that is output via the serial communications port every 10 seconds. Typically this message is processed by an externally installed AIS module, however by itself it is a quick summary of the lantern's operating status. This detail is also displayed on the INFO tab.

Optional GPS Synchronisation

The lanterns can be fitted with a GPS module, and provide the user with the ability to install independently operating lanterns that all flash in synchronisation. No additional power supplies, aerials or control systems are required, and with its microprocessor based system, the GPS option is specifically designed to provide maximum reliability and performance over a wide range of environmental conditions.

Operating Principle

Each light operates independently and requires no operator intervention. A minimum of 4 satellites need to be in view for the built-in GPS receiver to collect time data. At dusk, the light sensor will turn the light on. If time data is available the light will come on synchronised to every other light with the same selected flash code.

Synchronisation is achieved using an internal algorithm based on the highly accurate time base and time data received from the satellites. The satellite data is provided from a number of earth stations using atomic clocks as the time base. Continuous self-checking ensures that the light will continue to run in synchronisation.

Light Activation

At power-up the microprocessor checks that the internal GPS module is programmed correctly and is able to provide valid time base and time data. Once outside with a clear view of the sky, valid data should become available within 20 minutes.

Standby Operation

During standby the microprocessor is in idle mode to reduce power consumption. The microprocessor will automatically exit the idle mode as soon as the lantern becomes active.

Active Operation

When the lantern is active it:

- Checks for valid time data and is turned on after a delay based on the current time and the length of the selected flash code.
- If valid time data is not detected the light will turn on after approximately 10 seconds. This light will not be synchronised.
- If the light turns on unsynchronised it will continually check for valid time data. Once valid data is found the light will automatically synchronise.

Note: Lights will not synchronise if different flash codes are selected.



Optional GSM Monitoring

The lanterns may also be fitted with GSM Cell-Phone Monitoring and Control – enabling users to access real-time diagnostics data and change lantern settings via cell-phone. Flash Codes and Intensity cannot be altered via GSM on the SL-LED-CTRL.

The system can also be configured to send out alarm SMS text messages to designated cellular telephone numbers. Users can also have alarms and reports sent to designated email addresses.

Please contact Sealite for further information and instructions.

Light Source & Pedestal Installation

Tools required

- 19mm spanner, or adjustable spanner
- 6mm Hex Allen Key
- Large Phillips PH3 screwdriver
- Spirit level

Initial Considerations

- Cable length and distance from controller
- Cable paths/exits
- Interface to mounting plate. Typical example PCD 170mm ~ 200mm with slots for M12 bolts

Procedure

1. The Pedestal Mount baseplate is designed to accommodate a three point mount at PCD from 170mm to 200mm with holes and slots to clear an M12 bolt.
2. This would typically be used with threaded rod or bolts to form an adjustable platform, as is found in many lighthouses.
3. The first step is to survey the installation and confirm the intended mounting method is suitable, then remove the existing lamp assembly.
4. Feed the cable from the Controller to the mounting area, then through the bottom of pedestal baseplate, into gland as shown and pull through into terminal block enclosure. See Step 12 for Details on Wiring the 30Pin Connector.
5. Ensure there is sufficient cable slack to terminate the wires, but leave wire termination until later stage
6. Mount the Pedestal and Light Source at approximately the correct position and tighten the nuts. Be care not to touch the LEDs during the assembly process.
7. Next replace the Light Source with the Aiming Tool. The Light source is removed by loosening the M16 nut at the base of the unit, then carefully unscrewing the assembly off the thread, and then carefully placing aside. Take care not to bump or scratch the LEDs.
8. The Aiming Tool is mounted in reverse fashion by screwing it onto the M16 All-Thread.
9. Begin the alignment procedure by loosening the 3 point mount. The procedure will differ across sites depending on the lens assembly and available equipment, and relies on the installers knowledge and experience.
10. The basic alignment method begins with levelling the mount at approximately the correct height.
11. Once the mount is level, the height and position should be adjusted until the top of the aiming tool is at the focal point of the lens. Most adjustment should be obtained with the 3 point mount. The Light Source may be adjusted on the pedestal by repositioning along the slot and by screwing the M16 All-Thread up and down on the Pedestal.
12. When fitting the 30Pin Connector to the extension cable running between the Light Source and the Control Box use the diagram below for correct pin location in the connector. Slide the Compression Nut and Backshell onto the cable before stripping and Pinning each cable.




Manual Information Tab

Wiring Matrix for SL-LED-CTRL Extension Cable


| 31-Way connector | | | BOARD | | BOARD |
|-----------------------|-------------------|-----|--------|---------|-------|
| Description | Board Description | PIN | Master | LED No. | Slave |
| LED1+ | LED A | 1 | LED1 | 1 | |
| LED1- | LED K | 2 | LED1 | | |
| LED2+ | LED A | 3 | | 2 | LED1 |
| LED2- | LED K | 4 | | | LED1 |
| LED3+ | LED A | 5 | LED2 | 3 | |
| LED3- | LED K | 6 | LED2 | | |
| LED4+ | LED A | 7 | | 4 | LED2 |
| LED4- | LED K | 8 | | | LED2 |
| LED5+ | LED A | 9 | LED3 | 5 | |
| LED5- | LED K | 10 | LED3 | | |
| LED6+ | LED A | 11 | | 6 | LED3 |
| LED6- | LED K | 12 | | | LED3 |
| LED7+ | LED A | 13 | LED4 | 7 | |
| LED7- | LED K | 14 | LED4 | | |
| LED8+ | LED A | 15 | | 8 | LED4 |
| LED8- | LED K | 16 | | | LED4 |
| LED9+ | LED A | 17 | LED5 | 9 | |
| LED9- | LED K | 18 | LED5 | | |
| LED10+ | LED A | 19 | | 10 | LED5 |
| LED10- | LED K | 20 | | | LED5 |
| LED11+ | LED A | 21 | LED6 | 11 | |
| LED11- | LED K | 22 | LED6 | | |
| LED12+ | LED A | 23 | | 12 | LED6 |
| LED12- | LED K | 24 | | | |
| Empty / Not Used | | | | | |
| Empty / Not Used | | | | | |
| Thermistor (+3v3) | | | | | |
| Thermistor RTN (Temp) | | | | | |
| Empty / Not Used | | | | | |
| Empty / Not Used | | | | | |

| | |
|--------------------------|---|
| Name: | Light Head Connector and Male End of Extension Lead |
| Backshell Colour: | Blue |
| Pin Type: | Male |



View from Rear of Connector

| | |
|--------------------------|--|
| Name: | Control Box Connector and Female End of Extension Lead |
| Backshell Colour: | Grey |
| Pin Type: | Female |



View from Rear of Connector

We at Sealite have utilised the Deutsch Industrial Connectors to join connect our Light Source to the Control Box.

Below is a list of the part numbers for each connector

| Deutsch Part No. | Description |
|---------------------------|--|
| HDP24-24-31ST-L015 | Receptacle for socket contacts + L015 threaded adaptor (Grey Threaded End) |
| HDP26-24-31PE-L015 | Plug for pin contacts + L015 threaded adaptor (Blue Threaded End) |
| M902-2053 | HD10 Compression nut for backshell |
| M902-2243 | Backshell for L015 adaptor |
| 0462-201-1631 | Deutsch contact Female #16 (Blue Threaded End) |
| 0460-202-1631 | Deutsch contact Male #16 (Grey Threaded End) |

Important: To crimp the Contacts on to the wire ALWAYS use a #16 Crimping Tool that is compatible with Deutsch Industrial Connectors



External Antenna, GSM

The GSM external antenna comprises of a GSM antenna mounted to 115mm x 40mm enclosure, fitted with a 3m long cable terminated with a Bulgin PX0409 connector.

The Enclosure mounts via an external plate.

The cable plugs into connector on SL-LED-CTRL.

Other options available upon request.




External Antenna, GPS

Sealite offers high gain antenna GPS antenna, mounted to a "L" bracket as shown.

Coaxial cable lengths may be specified which plugs into connector on SL-LED-CTRL.

Other options available upon request.



External Light Sensor (PE Cell)

Existing photocells may be interfaced with the controller depending on electrical parameters. Some sensors may not be shared with other equipment. Please consult with Sealite for details.

Typically mount facing away from equator, not pointing east nor west, to avoid direct sunlight. May be mounted externally to building with due care to environmental debris build up, bird fouling, and access for cleaning.

The Sealite External Light Sensor (PE Cell) comprises of a standard PE cell mounted to 115mm x 40mm enclosure, fitted with a 3m long cable terminated with a Bulgin connector.

The Enclosure mounts via an external plate at two dia 4.5mm mounting points.

The Photocell is terminated with a connector labelled “External Light Sensor” which connects to the SL-LED-CTRL driver.

Other options available upon request.





Maintenance

Take care with AC units. Exposed mains potential. Inspection with lid removed only be performed by qualified personnel.

1. AC units : Green LED indicates power supply is energised
2. AC units : Mains fuse (check with multimeter)
3. Board status LEDs (refer next page)
4. GSM status LEDs (refer to the GSM manual)



Board LED indicators

There are two LED indicators present on the circuit board.

Red status indicator

This indicates the supply voltage level.

- Steady on,, the flat battery cut off is in effect. The battery has been below the manually set FLAT threshold for at least 12 seconds. Default FLAT setting is 22.0v
- Slow flashing, the battery voltage is high, above 29.0v
- Off, the battery voltage is optimal, between 27.0v and 29.0v
- 1 Quick flash, the battery voltage is good, between 25.0v and 27.0v
- 2 Quick flashes, the battery voltage is ok, between 23.0v and 25.0v
- 3 Quick flashes, the battery voltage is low, between 22.0v and 23.0v
- 4 Quick flashes, the battery voltage is flat, below 22.0v

Yellow status indicator

- Off, daylight or standby
- Fast flashing, day to night transition is evaluated
- 1 Quick flash, night operation, synchronization in process
- 2 Quick flashes, night operation, not synchronized yet

General maintenance

- LED light source – do not clean LEDs with abrasive cleaners or chemicals!
- Use compressed air to remove debris.
- If absolutely necessary use IPA with lens cloth, but ensure there are no particles or debris that may rub and scratch the lens.
- Ensure heatsink fins are free of debris, webs and any other contamination that will impede air flow and cause heat build-up.

Trouble Shooting

| Problem | Remedy |
|--|--|
| Unable to communicate with lantern via USB | <ol style="list-style-type: none">1. If unit is fitted with GSM capabilities. Make sure the correct cable is connected to the RS232 port on the master board.2. Connect the USB drive provided by Sealite to the PC and open to view files.3. Double-click on the file: Configx.xx.exe (note, version number may vary).4. Extract the executable file.5. Connect the lantern to a power source.6. Connect the lantern to the PC.7. Click "COM Setup".8. Select the appropriate COM Port from the drop down menu in the "Serial Port" dialogue box.9. Ensure the "Open Port" check box is selected and "Port is Open" is displayed.10. Click "OK".11. Lantern should be connected and ready for programming |
| System will not activate. | <ul style="list-style-type: none">• Ensure Light Sensor is in darkness.• Wait at least 60 seconds for the program to initialise in darkness.• Ensure battery terminals are properly connected.• Ensure SL-LED-CTRL is connected to a 24 Volt power supply |
| Programming settings will not change | <ul style="list-style-type: none">• Check programming cable is properly connected to both lantern and computer, and check that the lantern is connected correctly to a power source (and that the power source is charged eg. battery). |

Sealite Warranty

Refer to sealite.com for our Warranty Terms and Conditions.



We believe technology improves navigation™

sealite.com info@sealite.com

Sealite Pty Ltd
Australia
+61 (0)3 5977 6128

Sealite Asia Pte Ltd
Singapore
+65 6908 2917

Sealite United Kingdom Ltd
UK
+44 (0) 1502 588026

Sealite USA LLC
USA
+1 (603) 737 1311